



AJS **JAVELIN STOPBOARD INSTALLATION INSTRUCTIONS & PARTS LIST**

INSTALLATION:

- 1. Position the stopboard (Item no. 1A & 1B) in place. The sector lines of the stopboard should line up with the sector lines on the track (or throwing surface), and be centered in the throwing sector (See Drawing No. AJS-C-001 for diagram). Establish the locations for installing the concrete anchors, and use a permanent marker to mark their positions (6 places).
- 2. Remove the stopboard. Using a 3/4" diameter masonry bit (not included), drill 2 (two) holes, 2-1/2" deep, at the marked locations.
- 3. Install concrete expansions shields (Item No. 2), threaded side down, into the holes and tap flush with the concrete surface.
- 4. Set stopboard back into place and attach with 3/8"-16 x 3" flathead screw (Item No. 3). Tighten screws firmly to expand concrete anchors into place.

PARTS LIST:

- 1/4" high x 2-3/4" wide x 15'-10" aluminum stopboard, 1. AJS Stopboard 2 13' -1-1/2" sector
- 2. Expansion Shield 3/8"-16 x 2" Loxin machine bolt concrete double expansion 6 shield 6
- 3. Flathead Screw 3/8"-16 x 3" flathead screw, s.s.

FOR TECHNICAL ASSISTANCE, CALL 1-800-523-5471

K:\AAE Data\PDF Files\Product Instructions & Parts Lists\Track & Field\Ajs\AJS Assembly Instructions.doc Copyright © 2002 Aluminum Athletic Equipment Co.

Page 1 of 1