


## **RJS** Regulation High Jump Standards









## RJS REGULATION HIGH JUMP STANDARD PARTS LIST & ASSEMBLY INSTRUCTIONS

Pt.#	ltem	Description	Qty.
1	C-Channel	1-5/8" x 2" x 90" long, Aluminum "box-end" channel, 6063T6	2
2	Base	Steel base	2
3	End Cap	1-1/2" x 2" black plastic cap	2
4	Bolt	1/4"-20 x 1" hex bolt, stainless steel	8
5	Axle	3/8" dia. x 1-1/2" long shoulder screw, stainless steel, 5/16" dia. thread size	4
6	Wheel	#4 - 2" dia. rubber wheel, 3/8" bore	4
7	Nut	5/16" thin nylon-insert lock nut	4
8	Knob	Knurled plastic knob, 1-7/8" x 1",	2
		5/16"-18 thread	
9	Nut	1/4"-20 wiz-lock nut, stainless steel	12
10	Bolt	1/4"-20 x 1-3/4" R.H. machine screw, stainless steel	4
11	Cap Nut	5/16"-18, nylon insert locking cap nut	2
12	Slider	UHMW slider, 4" long	2
13	Slider Body	Cast aluminum slider, custom	2
14	Decal	Decal, 4'-0" - 7'-0", 1/4" increments, pressure-sensitive, black on clear	2*

\* 1 RH, 1 LH Required

## **ASSEMBLY**

- 1. Assemble High Jump Standard (Item No. 1) to steel base (Item No. 2) with 1/4"-20 bolts and nuts (Item Nos. 4 & 9). Tighten bolts securely. Repeat for other standard.
- 2. Place the standards so they face each other (as if they were being placed in front of the High Jump pit). Install axle/wheel assembly (Item Nos. 5, 6, & 7) into 1/4" hole in steel base **toward the** <u>outside</u> of the pit. (The side where the adjustment knob is. For illustration, see Dwg. No. RJS-C-002). Repeat for the other wheel.

K:\AAE Data\Product Instructions & Parts Lists\Track & Field\RJS Assembly Instructions.doc Copyright © 2012 Aluminum Athletic Equipment Co.